



# TracVision® A5 AC/DC Converter Wiring Instructions

The following instructions explain how to wire the AC/DC converter between the TracVision A5 receiver and the vehicle's AC power supply.



**Figure 1**  
*AC/DC Converter and  
Connecting Cables*

1. Plug the AC/DC converter's receiver power cable into the "Vehicle Power" jack on the TracVision A5 receiver's rear panel.



**Figure 2**  
*TracVision A5 Receiver  
Power Connection*

2. Plug the AC/DC converter's AC power cord into the vehicle's AC power supply.